







BLACK (PL)



# NAUTILUS

MODEL  
ADD. A BALL

ABBREVIATIONS USED	WIRE COLOR CODE
ADJ. ADJUSTMENT	M. MILION
ADD. ADDITIONAL	PL. PLASTIC
ADV. ADVANCE	POS. POSITION
R.O. ROLL OVER	PT. POINT
BOT. BOTTOM	R. RIGHT
DU. DRUM UNIT	RE. RELAY
E.O.S. END OF STROKE	SEQ. SEQUENCE
IMP. IMPULSE	S.U. STEP UNIT
IND. INDEX	SW. SWITCH
L. LEFT	K. 1000

SWITCH SYMBOLS	WIRE COLOR CODE
NORMALLY OPEN SWITCH CLOSED WHEN ENERGIZED	BL. BLUE
NORMALLY CLOSED SWITCH OPEN WHEN ENERGIZED	BR. BROWN
SWITCH CONTAINED WITHIN A CIRCLE INDICATES OPERATION BY A MOTOR CAM	R. RED
MAKE-BREAK SWITCH	O. ORANGE
EXAMPLE: BL-W = BLUE WITH A WHITE TRACER	Y. YELLOW
BL+W = BLUE AND WHITE MOTTLED	G. GREEN
	B. BLUE
	V. VIOLET
	S. SLATE
	W. WHITE

RELAY COIL LOCATIONS	PT. RE (A)	F14
ADV. HOLE SCORE RE	F14	F14
ADV. SERPENT RE	F14	F14
ALTERNATOR RE	F14	F14
BALL INDEX RE	F14	F14
BONUS RE	F14	F14
COIN RE	F14	F14
2nd COIN SW RE	F14	F14
CREDIT RE	F14	F14
2nd CREDIT RE	F14	F14
DOUBLE BONUS RE	F14	F14

COIL LOCATIONS	PT. RE (A)	F14
BALL COUNT RESET	F14	F14
BALL COUNT S.U.	F14	F14
BALL RELEASE COIL	F14	F14
BANK TARGETS (2)	F14	F14
BONUS UNIT RESET	F14	F14
BONUS UNIT S.U.	F14	F14

